★ Heart rate Table of Contents ★ Music control When carrying out usual maintenance, please ensure practice of the following Do's and Do not expose your Activity Tracker to liquid, moisture, humidity, or rain while ch Zewa Activity Tracker 21200 can track your activity and aerobic fitness Following the steps of LIGHT IT UP to read the data you in anytime.It is designed to measure the walking steps, distance,con-Or scan this QR code with your phone: safe use of this product and protect you and others from injury. Please Long press the screen, swipe to choose, click to confirm. kindly find the meanings of the warning signs and symbols, which y Download more from APP, Open APP---Device---Watch Face, • DO use a wet soft cloth, dipped into water and wrung out, to wipe the dirt. Then use a dry Tap the touch key at any time to light up the Activity Tracket soft cloth to dry up the device. ou can choose Online Dial or Custom Dial with your phone display the time first. Tap the touch key each time, it will display the da This device has Bluetooth 5.0 technology, the user can set personal information such as height, weight, goal step and so on through the DON'T wash the device with water or immerse it in water. Caution: The user is cautioned that changes or modifications not expressly approved by according order set from Zewa APP. If there is no operation, it will tur · DON'T use propellant, abrasive or other chemicals to wipe the dirt in avoidance of • Do not use abrasive cleaners to clean your Activity Tracke Bluetooth devices, and then the information can be downloaded to not expose your Activity Tracker to extremely high or low temperatur Activity Tracker 21200. The data in the Activity Tracker also can be • DON'T disassemble this device. If you have any problems, please contact Zewa. After wearing the watch correctly, open the "Sleep" in the watch; record the sleep status throughout the night. the user can check it in anytime. credentials or create a new user account by selecting "Other login Options." Notes: The data of the day will be cleared to zero automatically when the time When using it, please click "Device-Take Picture" on the APP not insert anything into your Activity Tracker unless otherwise specified in the 0:00. The data cannot be cleared to zero manually. .....9 b. Single point of touch function and color display screen ......9 c. Keep a record of the measuring data during 7 days • This warranty does NOT cover damages caused by misuse or abuse, including but not ..... 10 d. Display walking steps, walking distance, the consumed calories Yoga, Basketball, Football, Badminto, Free Training etc. → Failure caused by unauthorized repairs or modifications; not attempt to replace your Activity Tracker's battery. It is built-in and not changeable. To access all Sports Modes select the "Sports" icon and Follow the tips in the manual to wear the Activity Tracker . Then it can → Damage caused by shock or drop during transportation; Sleeping monitoring ightarrow Failure caused by improper operation inconsistent with the instructions stated in this Pair Activity Activity Tracker to the App. g. Accurate step-counting The App is OFF.  $\rightarrow$  Malfunction or damage from failure to provide the recommended maintenance; h. Automatic identify running function • In the app, tap on "Device" at the bottom of your scre Should this device require maintenance (or replacement at our option) under warranty please deliver the original package to Zewa prepaid. Please return the store receipt (with dispose of your Activity Tracker in a fire. The battery could explode causing injury **★** Device Components Confirm pairing by pressing ( ) on the Activity Tracker display. the retail purchase date) and a note with reasons to return on it as well. **★** Message notification WARNING: THIS Activity Tracker IS NOT A MEDICAL DEVICE, The Activity Tracker and ★ Shortcut menu associated applications should not be used to diagnose, treat, or prevent any disea Bluetooth 5.0 technology if you have paired up with it. nedical condition. Always seek the advice of a qualified medical professional befor Do not disturb
Z. Vibration mode making any changes to your exercise, sleep or nutrition, as doing so may cause ★ Step counting Thank you very much for selecting Activity Tracker 21200. 3. Flashlight 4. Brightness ◆ Please read the user manual carefully and thoroughly so as to ensure in the watch: display the number of steps, calories, distance the safe usage of this product and keep the manual well for further reference Baseball Dance Pingpong Hockey Pilates Taekwondo · Dispose of the Activity Tracker, the Activity Tracker's battery in accordance with and other parameters of the day's exercise. susceptible to damage if used improperly. Please read the safety guidelines on the regulations. Do not dispose of the battery with regular household waste Recycle your package in accordance with local regulations. Handball Hip-hop Volleyball Tennis Darts Gymnastics